

# **Makerbase Web-Print Manual**

# 1. Device Controllers Required

(1)

- 1). Motherboard: MKS BASE, MKS GEN, MKS SBASE, etc. Based on open source mainboard.
- 2). MKS Touch screen: MKS TFT24, MKS TFT35 or MKS TFT70.
- 3). Wireless module: MKS TFT-WIFI

Note: MKS TFT-WIFI module must work together with MKS TFT series touchscreen.

(2)

- 1). MKS Robin kit
- 2). MKS Robin-WIFI Module

(3)

MKS PAD7 works independently, which has wifi module built-in already.

# 2. Web-Print Mode Introduction

#### 2.1 Cloud Print Mode

It is recommended when router is available to Internet. Printer is ability to connect Cloud after successfully configure network parameters of WIFI module. That you can powerful control your printers by APP or MKS Cloud platform from anywhere around the world. Certainly, it is capable to monitor printers by LAN on host-software, such as Printrun, proterface.



#### 2.2 LAN Print Mode

If WIFI router can 't access to the Internet or at a slow speed, recommend this mode. You can remote monitor of all your 3D printers. Start, stop, pause or edit prints, etc.

#### 2.3 AP Mode

This mode will activate under following network environment.

- a. Without wifi router.
- b. WIFI is unconfigured.
- c. WIFI is configuered, but unable to connect.


Then, the WIFI will generates a open hotspot "MKSWIFI-XXXX" which enter freely without password. Support to control printers by APP, Web, Host-software.

#### 2.4 WebServer Mode

Not recommend. Because it controls machines on LAN. If you want to activate APP, wifi firmware upgraded is required.



# 3. Cloud Mode



# 3.1 WIFI Config

# 3.1.1 MKS TFT-WIFI

Please configure wifi firmware as follow:

mks_config.txt	Tip
#wifi type(0: MKS TFT-WIFI 1:MKS HLK-WIFI	Select : MKS TFT-WIFI
>cfg_wifi_type:0	
#wifi mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the WIFI name as the same as
>cfg_wifi_ap_name:TP-LINK_C944	the router required.
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
#cloud services(0:disable;1:enable)	Not require to edit.
>cfg_cloud_enable:1	
#cloud ip	



>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	
# dynamic IP	
>cfg_ip_dhcp_flag:1	
#IP/mask/gateway	
>cfg_ip_address:192.168.3.100	
>cfg_ip_mask:255.255.255.0	
>cfg_ip_gate:192.168.3.1	


## 3.1.2 MKS Robin-WIFI

robin_config.txt	Tip
#wifi mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the wifi name as the same as
>cfg_wifi_ap_name:TP-LINK_C944	the router required.
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
#cloud services(0:disable;1:enable)	Not require to edit.
>cfg_cloud_enable:1	
# cloud ip	
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	



#### 3.1.3 MKS PAD

## Find wifi in Tools interface and connect. As follow:




## 3.2 Firmware Upgrade

# 3.2.1 Copy latest firmware to root of SD card, include:


robin_config.txt robin.bin MksWiFi.bin mks_pic	robin_config.txt robin.bin MksWiFi.bin mks_pic	MKS Robin
MksWiFi.bin mkstft28.bin mks_config.txt mks_pic	MksWifi.bin mkstft28.bin mks_config.txt mks_pic	MKS TFT



- 3.2.2 Notes on Upgrade
- a. Document names are not allowed to edit. Or will fail to upgrade.
- b. The document names will get changed after update successfully.
- c. Available to check current version in About interface.
  - 3.2.3 Greatly, it is able to upgrade WIFI firmware by WEB. At same LAN, enter IP on PC, then go into web. As follow:








**Edit parameters and print** 



#### 3.4 Host-Software

#### 3.4.1 Printrun



① Here is "IP+:8080", which is easy to find in WIFI setting.

For example: 192.168.0.114:8080.

② Baudrate: 115200

③ Connect.


④ It means that get connected successfully when the icons can control.

⑤ Print from SD card or PC are available.

6 Check out the responds from printer.



# 4. LAN Print Mode



# 4.1 WIFI Config

# 4.1.1 MKS TFT-WIFI

mks_config.txt	Tip
#wifi type(0: MKS TFT-WIFI 1:MKS HLK-WIFI)	Select : MKS TFT-WIFI
>cfg_wifi_type:0	
#wifi Mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the WIFI name as the same as
>cfg_wifi_ap_name:TP-LINK_C944	the router required.
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
# cloud services(0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when control via
# cloud ip	LAN.



>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	
# dynamic IP	
>cfg_ip_dhcp_flag:1	
# IP/mask/gateway	
>cfg_ip_address:192.168.3.100	
>cfg_ip_mask:255.255.255.0	
>cfg_ip_gate:192.168.3.1	

# 4.1.2 MKS Robin-WIFI Config

robin_config.txt	Tip
#wifi mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the WIFI name as the same
>cfg_wifi_ap_name:TP-LINK_C944	as the router required.
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
# cloud services (0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when control via
# cloud ip	LAN.
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	

# 4.1.3 MKS PAD

MKS PAD doesn't support APP LAN at present.



# 4.2 Software Upgrade

4.2.1 Copy latest firmware to root of SD card, includes:


robin_config.txt robin.bin MksWifi.bin mks_pic	robin_config.txt robin.bin MksWiFi.bin mks_pic	MKS Robin
MksWiFi.bin	MksWifi.bin	
mkstft28.bin	mkstft28.bin	MKS TFT
mks_config.txt	mks_config.txt	
mks_pic	Mks_pic	

## Notes on Upgrade

- a. Document names are not allowed to edit. Or will fail to upgrade.
- b. The document names will get changed after update successfully.
- c. Available to check current version in About interface.
  - 4.2.2 Greatly, it is able to upgrade WIFI firmware by WEB. At same LAN, enter IP on PC, then go into web. As follow:


Greatly, it is able to upgrade WIFI firmware by WEB. At same LAN, enter IP on PC, then go into web. As follow:








#### **4.3** APP





## 4.4 Host-Software

#### 4.4.1 Printrun



①Here is "IP+:8080", which is essy to find in WIFI setting.

For example: 192.168.0.114:8080.

②Baudrate: 115200

③Connect.


4 It means that get connected successfully when the icons can control.

⑤ Print from SD card or PC are available.

**©**Check out the responds from printer.



# 5 AP Print Mode



Feature: The WIFI will generate a open hotspot "MKSWIFI-XXXX" which is no password required, can be connected directly.



# 5.1 WIFI

# 5.1.1 MKS TFT-WIFI

mks_config.txt	Tip
#wifi type(0: MKS TFT-WIFI 1:MKS HLK-WIFI	Select : MKS TFT-WIFI
>cfg_wifi_type:0	
#wifi mode(0:sta;1:ap)	Select AP mode, and take WIFI
>cfg_wifi_mode:1	module as a hotspot.
#wifi name	Set name freely.
>cfg_wifi_ap_name:TEST-WIFI	
#wifipassword	Set wifi password freely.
>cfg_wifi_key_code:makerbase	
#Cloud(0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when select AP
# cloud ip	mode.
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	
# dynamic IP	
>cfg_ip_dhcp_flag:1	
# IP/mask/gateway	
>cfg_ip_address:192.168.3.100	
>cfg_ip_mask:255.255.255.0	
>cfg_ip_gate:192.168.3.1	

## 5.1.2 MKS Robin-WIFI

robin_config.txt	Tip
#wifi mode(0:sta;1:ap)	Select AP mode, set it as a
>cfg_wifi_mode:0	hotspot.
#wifi name	Set name freely.
>cfg_wifi_ap_name:TP-LINK_C944	



#wifi 密码	Set wifi password freely.
>cfg_wifi_key_code:makerbase	
# cloud services(0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when select AP
# cloud ip	mode.
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	

5.1.3 MKS PAD MKS PAD doesn't support AP mode at present.

# 5.2 Software Upgrade


Upload the latest firmware to wifi module.

# 5.3 Notes on Upgrade

- a. Document names are not allowed to edit. Or will fail to upgrade.
- b. The document names will get changed after update successfully.
- c. Available to check current version in About interface.



#### 5.4 Printrun



①Here is "IP+:8080", which is essy to find in WIFI setting.

For example: 192.168.0.114:8080.

②Baudrate: 115200

③Connect.


4 It means that get connected successfully when the icons can control.

⑤ Print from SD card or PC are available.

**©**Check out the responds from printer.



# 6 Web Server





# 6.1 WIFI

# 6.1.1 MKS TTFWIFI

mks_config.txt	Tip
#wifi type(0: MKS TFT-WIFI 1:MKS HLK-WIFI)	Select : MKS TFT-WIFI
>cfg_wifi_type:0	
#wifi Mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the WIFI name that you will
>cfg_wifi_ap_name:TP-LINK_C944	connect .
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
# cloud services(0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when control via
# cloud ip	LAN.
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	
# dynamic IP	
>cfg_ip_dhcp_flag:1	
# IP/mask/gateway	
>cfg_ip_address:192.168.3.100	
>cfg_ip_mask:255.255.255.0	
>cfg_ip_gate:192.168.3.1	




## 6.1.2 MKS ROBIN

robin_config.txt	Tip
#wifi mode(0:sta;1:ap)	Select : STA
>cfg_wifi_mode:0	
#wifi name	Set the WIFI name that you will
>cfg_wifi_ap_name:TP-LINK_C944	connect .
#wifi password	Set the password as the same as
>cfg_wifi_key_code:makerbase	the router required.
# cloud services (0:disable;1:enable)	Disabled cloud services is
>cfg_cloud_enable:0	recommended when control via
# cloud ip	LAN.
>cfg_wifi_cloud_host:www.baizhongyun.cn	
# cloud services port	
>cfg_cloud_port:10086	

# 6.1.3 MKS PAD


Find wifi in Tools interface and connect. As follow:





### 6.1.4 Firmware Upgrade

Note: Please upgrade wifi firmware which can support Web. As follow:






## 6.1.5 Notes on Upgrade

- d. Document names are not allowed to edit. Or will fail to upgrade.
- e. The document names will get changed after update successfully.
- f. Available to check current version in About interface.

WIFI has following two versions: common version and Web version.



CS is regular version, available APP outer net or LAN control. Such as :file transfer by APP, Host-software control.

W is Web version, supports file transfer and printer control.





# 6.2 Web-printing

Wifi firmware upgraded is required if you want to control printer by Web. Includes:





Enter IP and then go to Console. (Only Chinese version)





# Printing interface







#### Tools interface.

